



# RECLINE

BY MOLLOYS

## Your Chair Explained

The picture below shows all 5-massage zones, plus the heat pad that is contained in your massage chair.



Please note that anyone with a medical device (e.g. pacemaker) or medical condition must consult with their doctor/healthcare professional before purchasing a massage system.



# RECLINE

BY MOLLOYS

## Your Massage Handset Explained

To get the best results from your Massage System, it is essential that you first understand the functions of the handset. Please take a little time to fully acquaint yourself with these functions and then adjust the speed and intensity of the massage, to suit your own requirements.

### 1. Power


This button switches the massage system on or off. Press the button to switch on (please note that the handset buttons will illuminate and the display will confirm that the massage system is active). To switch off, press the button again.

The massage system is programmed to allow 15 minutes of continual use, before automatically switching itself off.

Please note, when left inactive, the LCD illumination will switch off after 30 seconds, but will leave the functional buttons selected illuminated, until the system automatically switches itself off after 15 minutes.

When the massage system is switched off, the handset retains the last settings in its memory. When switched back on, the massage will automatically start with the last used settings.

Please note: the power button is designed to illuminate at all times (even when the rest of the handset is not illuminated) to show that the massage system has been successfully connected to the power supply.



1. Power



2. Selection Code



3. Pre Programmed Functions



4. Intensity



5. Speed



6. Heat



# RECLINE

## BY MOLLOYS

### Zone Selection Control

Please follow the steps below to get the best results from your massage system.



#### 2. Zone Selection Control

To choose the zones you wish to operate, simply press the appropriate zone selection buttons from 1 to 5.

Each button offers individual control of the selected zone, from top of the back (1) to the calves (5). As each button is selected, the zone button will glow and the display will confirm active zones. (Blue zones on LCD indicate active zone).



#### 3. Pre-Programmed Functions

Your massage system is equipped with 3 pre-programmed functions for your enjoyment:

**Wave:** Offers complete head to toe massage by operating each selected zone in turn, starting at the top back (zone 1) and working through to the calves (5).

This programme can be operated at any level of intensity and at any speed (see sections 4 & 5). You can select /de-select any zone by pressing the zone button (see section 2). Pressing the Wave button will return the system to the Manual zone select option.

**Tap:** On activation all selected zones are operated together in short bursts. Tap can be used on any combination of zones, or on all 5 zones at once. This programme can also be adjusted to operate at any level of intensity and at any speed (see sections 4 & 5).

You can also select /de-select any zone by pressing the zone button (see section 2). Pressing the Tap button will return the system to the Manual zone select option.

